



INSTALLATION INSTRUCTIONS

Accessory 17" SPARE WHEEL P/N 08W17-SJC-101A

Application 2009 PILOT

Publications No. All 40713
Issue Date OCT 2008

PARTS LIST


Spare wheel
(The illustration may differ from the actual wheel.)



6 Tire pressure information labels



Valve




TOOLS AND SUPPLIES REQUIRED

Isopropyl alcohol
Shop towel

SPECIFICATIONS

TIRE PRESSURE INFORMATION LABEL ID CODE



TIRE PRESSURE INFORMATION LABEL

09 PILOT:

Vehicle grade	Tire pressure information label ID code
4WD, 2WD	JC1SF

INSTALLATION

Customer Information: The information in this installation instruction is intended for use only by skilled technicians who have the proper tools, equipment, and training to correctly and safely add equipment to your vehicle. These procedures should not be attempted by “do-it-yourselfers.”

NOTE:

- Before attaching the tire pressure information label, check the grade of the vehicle and the ID code on the tire pressure information label.
 - Make sure to install the tires of the correct size.
 - Please refer to the vehicle owner’s manual for the spare wheel installation.
 - Use a tire changer to install and remove the tires as described in the Operation Manual provided with the tire changer. Do not use a tire lever to install and remove the tires as it may cause damage to the tire and spare wheel.
1. Open the driver’s door. Using isopropyl alcohol on a shop towel, thoroughly clean the area where the Tire Pressure Information Label will attach. Remove the adhesive backing from the label, and attach it on the standard tire pressure information label as shown.
Make sure to apply the correct tire pressure information label.

