

See the **To select a play mode** section that applies to your model to learn how to select a different play mode.

Select	Category/Play Mode
Disc 1	Search Playlists ■
Disc 2	Search Artists ■
Disc 3	Search Albums ■
Disc 4	Search Genres ■
Disc 5	Shuffle All Albums
Disc 6	Shuffle All Songs

- To use these play categories, first install and run Honda TTS. You'll find the Honda TTS software application on the Honda Music Link CD. **See the User's Guide on the Honda Music Link CD** for more information.

Customer Support

For more information about Honda Music Link, call Honda Automobile Customer Service at 1-800-999-1009, Monday thru Friday, 6 a.m. to 5 p.m. (PST) or visit <http://automobiles.honda.com>.



ACCORD PAGE 1 • CIVIC PAGE 2 • ODYSSEY PAGE 4 • PILOT PAGE 5 • CR-V PAGE 6
ELEMENT PAGE 7 • RIDGELINE PAGE 8 • S2000 PAGE 9

©2005 American Honda Motor Co., Inc.
All Rights Reserved.

American Honda accepts no responsibility for any lost data on an iPod, even if the data is lost while using this product.

Apple, the Apple logo, iPod, iPod, iTunes, FireWire, and Mac are trademarks of Apple Computer, Inc., registered in the U.S. and other countries.

Installation Note: Honda Music Link can be installed on *applicable* vehicles equipped with factory- and dealer-installed Honda CD players and CD changers. American Honda makes no guarantee that Music Link will operate or operate properly on vehicles equipped with a non-Honda CD changer or a non-Honda CD player.

Honda Music Link


Designed specifically for Honda vehicles, Honda Music Link allows you to play music from your Apple® iPod® on your vehicle's audio system. Once connected, you can use the controls on your vehicle's audio system to play music from your iPod, and it charges your iPod battery.

This Quick Reference Guide will help you get started using Music Link quickly. See the User's Guide on the Honda Music Link CD to learn how to use all of Music Link's features.

Connecting Your iPod

Switch your iPod to music mode. Find the Music Link cable installed inside the glove box, and plug it into the dock connector port located on the bottom of the iPod. When the Music Link cable is properly connected, a checkmark appears on the iPod screen (*right*), and the iPod can only be operated using your vehicle's audio system controls.

NOTE: Music Link can be used with iPod (4th generation or later), iPod mini®, and iPod nano®. It does not work with the iPod shuffle®. Make sure your iPod has been updated with the latest firmware from Apple.



Disconnecting Your iPod

To disconnect the iPod, squeeze both sides of the Music Link cable connector and unplug the cable. You can connect and disconnect your iPod while the audio system is on or off.

IMPORTANT:

- For your safety, do not connect or disconnect the iPod while driving.
- Secure the iPod in the glove box. Do not place it on or allow it to fall onto the vehicle floor, where it can get stuck under the brake pedal or accelerator pedal.
- Do not leave the iPod in the vehicle in high temperatures or expose it to extended periods of direct sunlight. Doing so may damage it.
- To avoid damaging the Music Link cable, do not pull strongly on the cable. Always keep the connector dry and cap the connector when it is not in use.

Using the Audio System Controls

Music Link allows you to use the buttons on your audio system to control iPod functions. There are two ways* to listen to music: You can *shuffle all albums* or *shuffle all songs*. Selecting disc number 5 on your audio system corresponds to the *shuffle all albums* play mode, while selecting disc number 6 corresponds to the *shuffle all songs* play mode.

NOTE: Honda factory-installed audio systems vary from model to model and may have different button names for the same functions.

Playing Music

1. Connect the iPod (see left), turn the ignition switch to the ON (II) or ACC (I) position, and turn on the audio system.
2. Select Music Link by pressing the CD/AUX or CD/AUX/XM button (depending on your Accord model). If the audio system plays a disc in the CD player/changer or plays the XM radio, press the CD/AUX or CD/AUX/XM button again. Music Link begins playback with the last song played on the iPod. If no song is queued, Music Link shuffles all songs in random order.

Selecting a Play Mode

- *To shuffle the albums* on your iPod in random order, use the DISC– and DISC+ buttons (Preset 5 and Preset 6, respectively) to scroll thru the disc numbers until **Disc 5** is displayed in the audio display. Then press and hold either SEEK/SKIP button (▶▶ or ◀◀) for at least 1 full second (or, on some models, until you hear a beep). After the album begins playing:
 - Press and release the SEEK/SKIP button to skip to the next song (◀▶) or the beginning of the song currently playing (▶▶) within an album.
 - Press and hold either SEEK/SKIP button (▶▶ or ◀◀) for at least 1 full second (or, on some models, until you hear a beep) to skip to the beginning of another album.
- *To shuffle all songs in random order*, use the DISC– and DISC+ buttons (Preset 5 and Preset 6, respectively) to scroll thru the disc numbers until **Disc 6** is displayed in the audio display. Then press and hold either SEEK/SKIP button (▶▶ or ◀◀) for at least 1 full second (or, on some models, until you hear a beep). After selecting this play mode, press and release the SEEK/SKIP button to skip to the next song (◀▶) or to skip to the beginning of the one currently playing (◀◀).

* See the User's Guide on the Honda Music Link CD for additional play modes/categories.

Using the Audio System Controls

Music Link allows you to use the buttons on your audio system to control iPod functions. There are two ways* to listen to music: You can *shuffle all albums* or *shuffle all songs*. Selecting disc number 5 on your audio system corresponds to the *shuffle all albums* play mode, while selecting disc number 6 corresponds to the *shuffle all songs* play mode.

NOTE: Honda factory-installed audio systems vary from model to model and may have different button names for the same functions.

Playing Music

1. Connect the iPod (see the inside front cover), turn the ignition switch to the ON (II) or ACC (I) position, and turn on the audio system.
2. Select Music Link by pressing the CD/AUX or XM/AUX button (depending on your Civic model). If the audio system plays a disc in the CD player/changer or plays the XM radio, press the CD/AUX or XM/AUX button again. Music Link begins playback with the last song played on the iPod. If no song is queued, Music Link shuffles all songs in random order.

Selecting a Play Mode

- To *shuffle the albums* on your iPod in random order, use the DISC+ and DISC– buttons (Preset 1 and Preset 4, respectively) to scroll thru the disc numbers until **Disc 5** is displayed in the audio display. Then press and hold either SEEK/SKIP button (▶▶ or ◀◀) for at least 1 full second (or, on some models, until you hear a beep). After the album begins playing:
 - Press and release the SEEK/SKIP button to skip to the next song (▶▶) or the beginning of the song currently playing (◀◀) within an album.
 - Press and hold either SEEK/SKIP button (▶▶ or ◀◀) for at least 1 full second (or, on some models, until you hear a beep) to skip to the beginning of another album.
- To *shuffle all songs in random order*, use the DISC+ and DISC– buttons (Preset 1 and Preset 4, respectively) to scroll thru the disc numbers until **Disc 6** is displayed. The selected disc is shown in the audio display. Then press and hold either SEEK/SKIP button (▶▶ or ◀◀) for at least 1 full second (or, on some models, until you hear a beep). After selecting this play mode, press and release the SEEK/SKIP button to skip to the next song (▶▶) or to skip to the beginning of the one currently playing (◀◀).

* See the User's Guide on the Honda Music Link CD for additional play modes/categories.

Using the Audio System Controls

Music Link allows you to use the buttons on your audio system to control iPod functions. There are two ways* to listen to music: You can *shuffle all albums* or *shuffle all songs*. Selecting disc number 5 on your audio system corresponds to the *shuffle all albums* play mode, while selecting disc number 6 corresponds to the *shuffle all songs* play mode.

NOTE: Honda factory-installed audio systems vary from model to model and may have different button names for the same functions.

Playing Music

1. Connect the iPod (see the inside front cover), turn the ignition switch to the ON (II) or ACC (I) position, and turn on the audio system.
2. Select Music Link by pressing the AUDIO button on your vehicle's audio system, then touch the CDC icon on the navigation system screen. Music Link begins playback with the last song played on the iPod. If no song is queued, Music Link shuffles all songs in random order.

Selecting a Play Mode

- To *shuffle the albums* on your iPod in random order, use the ▲TUNE/FOLDER▼ button to scroll thru the disc numbers until **Disc 5** is displayed in the navigation display. Then press either the Preset 3◀◀ or Preset 4▶▶ button. After the album begins playing:
 - Press the Preset 6▶▶▶ button to skip to the beginning of the next song within an album, or press the Preset 5◀◀◀ button to skip to the beginning of the song currently playing.
 - Press either the Preset 3◀◀ or Preset 4▶▶ button to skip to the beginning of another album.
- To *shuffle all songs in random order*, use the use the ▲TUNE/FOLDER▼ button to scroll thru the disc numbers until **Disc 6** is displayed in the navigation display. Then press either the Preset 3◀◀ or Preset 4▶▶ button. After selecting this play mode, press the Preset 6▶▶▶ button to skip to the beginning of the next song or press the Preset 5◀◀◀ button to skip to the beginning of the song currently playing.

* See the User's Guide on the Honda Music Link CD for additional play modes/categories.

Using the Audio System Controls

Music Link allows you to use the buttons on your audio system to control iPod functions. There are two ways* to listen to music: You can *shuffle all albums* or *shuffle all songs*. Selecting disc number 5 on your audio system corresponds to the *shuffle all albums* play mode, while selecting disc number 6 corresponds to the *shuffle all songs* play mode.

NOTE: Honda factory-installed audio systems vary from model to model and may have different button names for the same functions.

Playing Music

1. Connect the iPod (see the inside front cover), turn the ignition switch to the ON (II) or ACC (I) position, and turn on the audio system.
2. Select Music Link by pressing the AUX, AUX/XM, or DVD/AUX button (depending on your Odyssey model). If the audio system plays the XM radio, press the AUX/XM button again. Music Link begins playback with the last song played on the iPod. If no song is queued, Music Link shuffles all songs in random order.

Selecting a Play Mode

- To *shuffle the albums* on your iPod in random order, use the DISC– (Preset 5) and DISC+ (Preset 6) buttons to scroll thru the disc numbers until **Disc 5** is displayed in the audio display. Then press and hold either SEEK/SKIP button (– or +) for at least 1 full second (or, on some models, until you hear a beep). After the album begins playing:
 - Press and release the SEEK/SKIP button to skip to the next song (+) or the beginning of the song currently playing (–) within an album.
 - Press and hold either SEEK/SKIP button (– or +) for at least 1 full second (or, on some models, until you hear a beep) to skip to the beginning of another album.
- To *shuffle all songs in random order*, use the DISC– (Preset 5) and DISC+ (Preset 6) buttons to scroll thru the disc numbers until **Disc 6** is displayed in the audio display. Then press and hold either SEEK/SKIP button (– or +) for at least 1 full second (or, on some models, until you hear a beep). After selecting this play mode, press and release the SEEK/SKIP button to skip to the next song (+) or to skip to the beginning of the one currently playing (–).

* See the User's Guide on the Honda Music Link CD for additional play modes/categories.

Using the Audio System Controls

Music Link allows you to use the buttons on your audio system to control iPod functions. There are two ways* to listen to music: You can *shuffle all albums* or *shuffle all songs*. Selecting disc number 5 on your audio system corresponds to the *shuffle all albums* play mode, while selecting disc number 6 corresponds to the *shuffle all songs* play mode.

NOTE: Honda factory-installed audio systems vary from model to model and may have different button names for the same functions.

Playing Music

1. Connect the iPod (see the inside front cover), turn the ignition switch to the ON (II) or ACC (I) position, and turn on the audio system.
2. Select Music Link by:
 - **LX:** Pressing the CD/TAPE button on your vehicle's audio system.
 - **EX:** Pressing the AUX/XM button. If the audio system plays the XM radio, press the AUX/XM button repeatedly until CD4 is shown in the audio system display.

Music Link begins playback with the last song played on the iPod. If no song is queued, Music Link shuffles all songs in random order.

Selecting a Play Mode

- To *shuffle the albums* on your iPod, use the DISC– (Preset 5) and DISC+ (Preset 6) buttons to scroll thru the disc numbers until **Disc 5** is displayed in the audio display. Then press and hold either SEEK/SKIP button (◀/– or ▶/+) for at least 1 full second (or, on some models, until you hear a beep).
 - Press and release the SEEK/SKIP button to skip to the beginning of the next song (▶/+) or currently playing song (◀/–) within an album.
 - Press and hold either SEEK/SKIP button (◀/– or ▶/+) for at least 1 full second (or, on some models, until you hear a beep) to skip to the beginning of another album.
- To *shuffle all songs in random order*, use the DISC– (Preset 5) and DISC+ (Preset 6) buttons to scroll thru the disc numbers until **Disc 6** is displayed in the audio display. Then press and hold either SEEK/SKIP button (◀/– or ▶/+) for at least 1 full second (or, on some models, until you hear a beep). After selecting this play mode, press and release the SEEK/SKIP button to skip to the next song (▶/+) or to the beginning of the currently playing song (◀/–).

* See the User's Guide on the Honda Music Link CD for additional play modes/categories.

Using the Audio System Controls

Music Link allows you to use the buttons on your audio system to control iPod functions. There are two ways* to listen to music: You can *shuffle all albums* or *shuffle all songs*. Selecting disc number 5 on your audio system corresponds to the *shuffle all albums* play mode, while selecting disc number 6 corresponds to the *shuffle all songs* play mode.

NOTE: Honda factory-installed audio systems vary from model to model and may have different button names for the same functions.

Playing Music

1. Connect the iPod (see the inside front cover), turn the ignition switch to the ON (II) or ACC (II) position, and turn on the audio system.
2. Select Music Link by pressing the CD or CD/XM button (depending on your CR-V model). If the audio system plays a disc in the CD player or plays the XM radio, press the CD or CD/XM button again. Music Link begins playback with the last song played on the iPod. If no song is queued, Music Link shuffles all songs in random order.

Selecting a Play Mode

- To *shuffle the albums* on your iPod in random order, use the Preset 5 (backward) and Preset 6 (forward) buttons to scroll thru the disc numbers until **Disc 5** is displayed in the audio display. Then press and hold either SEEK/SKIP button (– or +) for at least 1 full second (or, on some models, until you hear a beep). After the album begins playing:
 - Press and release the SEEK/SKIP button to skip to the next song (+) or the beginning of the song currently playing (–) within an album.
 - Press and hold either SEEK/SKIP button (– or +) for at least 1 full second (or, on some models, until you hear a beep) to skip to the beginning of another album.
- To *shuffle all songs in random order*, use the Preset 5 (backward) and Preset 6 (forward) buttons to scroll thru the disc numbers until **Disc 6** is displayed in the audio display. Then press and hold either SEEK/SKIP button (– or +) for at least 1 full second (or, on some models, until you hear a beep.) After selecting this play mode, press and release the SEEK/SKIP button to skip to the next song (+) or to skip to the beginning of the one currently playing (–).

* See the User's Guide on the Honda Music Link CD for additional play modes/categories.

Using the Audio System Controls

Music Link allows you to use the buttons on your audio system to control iPod functions. There are two ways* to listen to music: You can *shuffle all albums* or *shuffle all songs*. Selecting disc number 5 on your audio system corresponds to the *shuffle all albums* play mode, while selecting disc number 6 corresponds to the *shuffle all songs* play mode.

NOTE: Honda factory-installed audio systems vary from model to model and may have different button names for the same functions.

Playing Music

1. Connect the iPod (see the inside front cover), turn the ignition switch to the ON (II) or ACC (II) position, and turn on the audio system.
2. Select Music Link by pressing the CD/AUX button. If the audio system plays a disc in the CD player/changer, press the CD/AUX button again. Music Link begins playback with the last song played on the iPod. If no song is queued, Music Link shuffles all songs in random order.

Selecting a Play Mode

- To *shuffle the albums* on your iPod in random order, use the DISC– and DISC+ buttons (Preset 5 and Preset 6, respectively) to scroll thru the disc numbers until **Disc 5** is displayed in the audio display. Then press and hold either SEEK/SKIP button (▶▶ or ◀◀) for at least 1 full second (or, on some models, until you hear a beep). After the album begins playing:
 - Press and release the SEEK/SKIP button to skip to the next song (▶▶) or the beginning of the song currently playing (◀◀) within an album.
 - Press and hold either SEEK/SKIP button (▶▶ or ◀◀) for at least 1 full second (or, on some models, until you hear a beep) to skip to the beginning of another album.
- To *shuffle all songs in random order*, use the DISC– and DISC+ buttons (Preset 5 and Preset 6, respectively) to scroll thru the disc numbers until **Disc 6** is displayed in the audio display. Then press and hold either SEEK/SKIP button (▶▶ or ◀◀) for at least 1 full second (or, on some models, until you hear a beep). After selecting this play mode, press and release the SEEK/SKIP button to skip to the next song (▶▶) or to skip to the beginning of the one currently playing (◀◀).

* See the User's Guide on the Honda Music Link CD for additional play modes/categories.

Using the Audio System Controls

Music Link allows you to use the buttons on your audio system to control iPod functions. There are two ways* to listen to music: You can *shuffle all albums* or *shuffle all songs*. Selecting disc number 5 on your audio system corresponds to the *shuffle all albums* play mode, while selecting disc number 6 corresponds to the *shuffle all songs* play mode.

NOTE: Honda factory-installed audio systems vary from model to model and may have different button names for the same functions.

Playing Music

1. Connect the iPod (see the inside front cover), turn the ignition switch to the ON (II) or ACC (I) position, and turn on the audio system.
2. Select Music Link by pressing the XM/AUX or CD/AUX button (depending on your Ridgeline model). If the audio system plays the XM radio or plays a disc in the CD player/changer, press the XM/AUX or CD/AUX button again. Music Link begins playback with the last song played on the iPod. If no song is queued, Music Link shuffles all songs in random order.

Selecting a Play Mode

- To *shuffle the albums* on your iPod in random order, use the DISC– and DISC+ buttons (Preset 5 and Preset 6, respectively) to scroll thru the disc numbers until **Disc 5** is displayed in the audio display. Then press and hold either SEEK/SKIP button (▶▶ or ◀◀) for at least 1 full second (or, on some models, until you hear a beep). After the album begins playing:
 - Press and release the SEEK/SKIP button to skip to the next song (▶▶) or the beginning of the song currently playing (◀◀) within an album.
 - Press and hold either SEEK/SKIP button (▶▶ or ◀◀) for at least 1 full second (or, on some models, until you hear a beep) to skip to the beginning of another album.
- To *shuffle all songs in random order*, use the DISC– and DISC+ buttons (Preset 5 and Preset 6, respectively) to scroll thru the disc numbers until **Disc 6** is displayed in the audio display. Then press and hold either SEEK/SKIP button (▶▶ or ◀◀) for at least 1 full second (or, on some models, until you hear a beep). After selecting this play mode, press and release the SEEK/SKIP button to skip to the next song (▶▶) or to skip to the beginning of the one currently playing (◀◀).

* See the User's Guide on the Honda Music Link CD for additional play modes/categories.

Using the Audio System Controls

Music Link allows you to use the buttons on your audio system to control iPod functions. There are two ways* to listen to music: You can *shuffle all albums* or *shuffle all songs*. Selecting disc number 5 on your audio system corresponds to the *shuffle all albums* play mode, while selecting disc number 6 corresponds to the *shuffle all songs* play mode.

NOTE: Honda factory-installed audio systems vary from model to model and may have different button names for the same functions.

Playing Music

1. Connect the iPod (see the inside front cover), turn the ignition switch to the ON (II) or ACC (I) position, and turn on the audio system.
2. Select Music Link by pressing the CD/XM button. If the audio system plays a disc in the CD player/changer or plays the XM radio, press the CD/XM button again. Music Link begins playback with the last song played on the iPod. If no song is queued, Music Link shuffles all songs in random order.

Selecting a Play Mode

- To *shuffle the albums* on your iPod in random order, use the DISC– and DISC+ buttons (Preset 5 and Preset 6, respectively) to scroll thru the disc numbers until **Disc 5** is displayed in the audio display. Then press and hold either SEEK/SKIP button (▶▶ or ◀◀) for at least 1 full second (or, on some models, until you hear a beep). After the album begins playing:
 - Press and release the SEEK/SKIP button to skip to the next song (▶▶) or the beginning of the song currently playing (◀◀) within an album.
 - Press and hold either SEEK/SKIP button (▶▶ or ◀◀) for at least 1 full second (or, on some models, until you hear a beep) to skip to the beginning of another album.
- To *shuffle all songs in random order*, use the DISC– and DISC+ buttons (Preset 5 and Preset 6, respectively) to scroll thru the disc numbers until **Disc 6** is displayed in the audio display. Then press and hold either SEEK/SKIP button (▶▶ or ◀◀) for at least 1 full second (or, on some models, until you hear a beep). After selecting this play mode, press and release the SEEK/SKIP button to skip to the next song (▶▶) or to skip to the beginning of the one currently playing (◀◀).

* See the User's Guide on the Honda Music Link CD for additional play modes/categories.