HONDA

INSTALLATION INSTRUCTIONS

PARTS LIST

Armrest box

Base

2 Socket bolts

Owner's manual

TOOLS AND SUPPLIES REQUIRED

Ratchet

10 mm and 17 mm Sockets

5 mm Hex wrench

Torque wrench

Utility knife

Tape measure

Felt-tip pen

INSTALLATION

NOTE: Be careful not to damage the seat-back when installing the armrest with storage compartment.


If the vehicle is equipped with an armrest, continue with step 1, otherwise go to step 5.

1. Zip open the existing armrest cover on the driver's seat, and pull back the cover as shown.


2. Remove the hex nut, small washer, and large washer that secures the existing armrest, and remove the armrest.

---

3. Release the velcro strap and unzip the seat-back cover, then fold back the seat-back cover and locate the preset in the foam.

VELCRO STRAP

ZIPPER

PRESET IN FOAM

4. Using a utility knife, cut out the foam preset to expose the armrest bracket.

ARMREST BRACKET

**UTILITY KNIFE**

FOAM (Cut out.)

5. Using a felt-tip pen and tape measure, measure and mark the seat-back cover as shown. Push in on the mark, and confirm that the mark is centered over the hole in the seat base.

SEAT-BACK COVER

FELT-TIP PEN

155 mm (Measure from the stitching)

70 mm

MARK

SEAT COVER (Measure from the upper seam)

6. Using a utility knife, make two 65 mm (2 1/2 in.) cuts in the seat-back cover to expose the seat base.

SEATBACK COVER

65 mm (2 1/2 in.)

65 mm (2 1/2 in.)

UTILITY KNIFE

AII 34107-40803 (0810)

7. Get the new base from the kit, and position it on the seat's pin base. Install the two socket bolts. Torque the socket bolts to 10-12 N·m (7-9 lbf·ft).

SOCKET BOLTS
Torque
10-12 N·m (7-9 lbf·ft)

PIN BASE

NEW BASE

8. Insert the armrest into the holes in the base and push on it until it clicks into position. The white recessed portion of the push knob should be visible.

ARMREST

BASE

PIN

PUSH KNOB

TAB

WHITE RECESSED PORTION

PUSH KNOB

PUSH KNOB

🔒 Lock   🔓 Unlock

9. Check that the armrest operates properly by moving it up and down with your hand.

10. To release the armrest, press on the push knob and pull out on the armrest.

11. Put the armrest owner's manual in the glove box.

AII 34107-40803 (0810)