| - 🔛 HONDA 🛛 | Accessory | Application | Publications No. |
|---|--|--|--------------------------------------|
| INSTALLATION INSTRUCTIONS | WOOD SELECT LEVER P/N 08U92-S9V-100 | 2007 PILOT | All 33089 Issue Date JULY 2006 |
| PARTS LIST | 2. | Attach a piece of electrical ta knob as shown. | pe on the new select |
| Select knob | | ELECTRICAL TAPE | |
| SUPPLIES REQUIRED | | | |
| INSTALLATION Remove the existing select kr counterclockwise. | nob by turning it | | NEW SELECT KNOB |
| T.C.C. | 3. EXISTING SELECT KNOB (Discard.) | Thread the new select knob of to 10 turns using the tape as overtighten the select knob. | |
| | 4. | Remove the tape. | |
| | | | |