	Accessory	Application	Publications No.
INSTALLATION	EXHAUST PIPE FINISHER	2008 ELEMENT	All 36530
INSTRUCTIONS	P/N 08F53-SCV-100		Issue Date MAY 2007
PARTS LIST		3. While pushing the exhaust pipe finisher firmly against the exhaust pipe, tighten the flange bolt. Torque the flange bolt to 10 N·m (7 lbs-ft.)	
Exhaust pipe finisher			
Flange bolt			EXHAUST PIPE FINISHER
TOOLS REQUIRED 10 mm Socket			
Torque wrench		FLANGE BOLT	
INSTALLATION		Torque: 10 N⋅m (7 lbs-ft)	
NOTE: Allow the exhaust pipe to cool down before you install the exhaust pipe finisher.		. Start the engine and rev it up a few times. Listen for vibration from the exhaust pipe finisher and adjust if necessary.	
 Partially thread the flange bolt into the exhaust pipe finisher. 			
EXHAUST PIPE FLANGE BOLT	EXHAUST PIPE FINISHER		
2. With the flange bolt facing down, slide the exhaust pipe finisher onto the exhaust pipe until it bottoms.			