

INSTALLATION INSTRUCTIONS

Accessory

LEATHER SHIFT KNOB (M/T) P/N 08U92-SDA-100A

Application

2007 ACCORD **2 AND 4-DOOR** Publications No.

All 32643

Issue Date **JULY 2006**

PARTS LIST

Leather shift knob




TOOLS REQUIRED


Long nose pliers

INSTALLATION


1. Squeeze the ring while you pull down on the shift boot. Remove the shift knob by turning it counterclockwise.




Remove the shift knob from the ring by squeezing the retaining tabs and pushing it up with long nose pliers.



Transfer the ring to the leather shift knob.



4. Install the leather shift knob on the shift lever by turning it in the clockwise direction.



5. Pull the boot upward.

USE AND CARE

- Use a sponge or cloth and a solution of mild liquid dishwashing soap and water to clean the shift knob.
- Rinse the knob completely with water, then dry it with a shop towel.
- Never use organic solvents such as benzene, thinner, or gasoline to clean the shift knob.