

**INSTALLATION
INSTRUCTIONS**

Accessory

**SHIFT KNOB (M/T)
P/N 08U92-SCV-100A**

Application

2009 ELEMENT

Publications No.

All 40723


Issue Date

OCT 2008**PARTS LIST**


Shift knob

**INSTALLATION**

1. Remove the shift knob by pulling down on the trim ring, and rotating it counterclockwise.



2. Install the new shift knob by rotating it clockwise. Adjust the knob so that the shift pattern on the top is in the correct direction.



3. Engage the cutouts in the trim ring with the retaining tabs of the knob by pulling the boot upward.