



INSTALLATION INSTRUCTIONS

Accessory

ALL-SEASON
FLOOR MATS

Application

2009 ELEMENT SC

Publications No.

All 40867


Issue Date

NOV 2008


Put this instruction in the glove box with the vehicle owner's manual.

PARTS LIST


Driver's side floor mat



Passenger's side floor mat



Rear floor mat




INSTALLATION

NOTE:

- A floor mat hook prevents the driver's side floor mat from sliding forward and possibly interfering with the pedals.
- If you remove the driver's side floor mat, make sure you reanchor it when you put it back in your vehicle.
- If you replace the floor mat, use factory floor mats designed to be used with the floor mat hook.
- Do not put additional floor mats on top of the anchored mat, otherwise the additional mats may slide forward and possibly interfere with the pedals.

Installing the Floor Mats

1. Install the driver's side floor mat by inserting the two front mat rings over the two floor mat hooks.



2. Install the passenger's side floor mat.
3. Install the rear floor mat by inserting the floor mat ring over the floor mat hook.

