


Installing the Anchors


- 1. Slide the driver's seat all the way back.
- 2. Under the front of the driver's seat cushion, extend the slits in the floor carpet with a utility knife (two places).



3. Push the lower tab of the anchor into the square hole concealed under the floor carpet. Pull the upper tab down and push it into the square hole in the anchor as shown. Repeat on the remaining anchor.

Installing the Floor Mats

4. Install the driver's side floor mat by placing the rings in the floor mat over the anchor pins.



- 5. Install the passenger's side floor mat.
- 6. Install the rear floor mat by placing the ring in the floor mat over the anchor pin.

