



# Honda Music Link 2.0

## Quick Reference Guide

# Getting Started Quickly



**HONDA**

## **Honda Music Link 2.0™**

Designed specifically for Honda vehicles, Honda Music Link 2.0 allows you to play music from your Apple iPod® on your vehicle's audio system. Once it's connected, you can use your audio unit's controls to play music from your iPod. It also charges the iPod's battery.

This Quick Reference Guide will help you get started using Honda Music Link. Refer to the User's Information Manual (available from <http://musiclink.honda.com>) to learn how to use all of Honda Music Link's features.

## **Connecting Your iPod**


Switch your iPod to music mode. Find the cable, installed inside your vehicle's glove box\*, and plug it into your iPod. When the Music Link cable is properly connected, the Honda logo appears on the screen of most iPods\*\*, and the iPod can be operated using only your vehicle's audio unit controls.

### **NOTE:**

Honda Music Link cannot be used with the iPod shuffle® or iPhone®.\*\*

## **Disconnecting Your iPod**

To disconnect your iPod, squeeze both sides of the Music Link cable connector, and unplug the cable. You can connect and disconnect your iPod whether the audio system is on or off.



\*In the S2000, the cable is located in the center console.

\*\*Refer to <http://musiclink.honda.com> for a list of compatible iPods.



NOTE: The audio unit does not display iPod text information.

### **IMPORTANT:**

- For your safety, do not connect or disconnect your iPod while driving.
- Secure the iPod in the glove box\*. Do not place it on or allow it to fall onto the vehicle floor, where it can get stuck under the brake pedal or accelerator pedal.
- Do not leave the iPod in the vehicle in high temperatures or expose it to extended periods of direct sunlight. Doing so may damage it.
- To avoid damaging the Music Link cable, do not pull strongly on the cable, keep the connector dry, and always cap the connector when it is not in use.

### **Using the Audio System Controls**

Honda Music Link uses the CD changer commands in your audio system to control iPod functions. Each disc number (1-7) corresponds to an exclusive playlist that you create in iTunes and save on your iPod.

DISC 1 – Honda1	DISC 6 – Honda6
DISC 2 – Honda2	DISC 7 – Honda7
DISC 3 – Honda3	DISC 8 – Shuffle All Songs
DISC 4 – Honda4	DISC 9 – Resume
DISC 5 – Honda5	

The songs on the iPod are still playable, even if no exclusive playlists have been created. In this case, only random playback of the iPod's entire library is selectable from the audio system.


\*In the S2000, secure your iPod in the center console.


## Creating Exclusive Playlists


- Playlists are defined as “Honda” + number (1 through 7): “Honda1,” “Honda2,” etc.
- Characters must be: uppercase “H,” lowercase “onda” and a number from 1 to 7. There is no space between the letter “a” and the number.
- Each playlist corresponds to a disc number and can be selected using the DISC+/-, FOLDER, or CATEGORY button\* on your audio unit.

 Honda1 — OK

 Honda 1 — Do not use a space between “Honda” and the number.


 HONDA1 — Do not use all-uppercase letters.

 honda1 — Do not use all-lowercase letters.

 Honda01 — Do not use a zero before the number.

## Playing Music

1. Connect your iPod, turn the ignition switch to ACC (I) or ON (II), and turn on the audio system.
2. To select Music Link, press one of the following buttons\* until **CDC** appears in the audio display: AUX, CD/AUX, CD/TAPE, CD/XM, or DVD/AUX.
3. Use the DISC +/-, FOLDER, or CATEGORY button\* to select a playlist.



Your iPod will initially play in Resume Mode (**DISC 9** appears on the display).

Resume Mode picks up the track that was playing before you connected the iPod.

You cannot re-select Resume Mode (**DISC 9**) after you've selected a playlist (**DISC 1-8**). Refer to the User's Information Manual for more details.

4. Use the SEEK/SKIP buttons to move to the next or previous track, or to rewind or fast-forward through a track.

\*The controls on Honda factory-installed audio systems vary depending on the model .  
Refer to your vehicle owner's manual.

### Customer Support

For more information about Honda Music Link 2.0, call Honda Automobile Customer Service at (800) 999-1009 Monday through Friday, 6 a.m. to 5 p.m. (Pacific Time), or visit <http://musiclink.honda.com>.

