



INSTALLATION INSTRUCTIONS

Accessory

HONDA MUSIC LINK

Application

2006 S2000


Publications No.
All 31273-31632

Issue Date
DEC 2005


PARTS LIST

Attachment Kit (Sold Separately)
P/N 08A28-1H1-800

4 Cushion tapes




Holder cushion




Grommet



8 Wire ties




2 Long wire ties




Music Link Adapter Kit (Sold Separately)
P/N 08A28-1H1-100A


Music Link adapter unit




Bus cable




Music Link harness



CD-ROM




Owner's manual



Bus Cable 2 Port (Sold Separately)
P/N 08A31-0F1-000


Bus cable 2 port



TOOLS AND SUPPLIES REQUIRED

#2 Phillips screwdriver
Flat-tip screwdriver
Diagonal cutters
Scissors
Ratchet
10 mm Socket
10 mm Combination wrench
Drill motor
Drill bit (3 mm)
Hole saw (20 mm)
Electrical tape
Pushpin
Eye protection
Isopropyl alcohol

Illustration of the Music Link System Installed on the vehicle




INSTALLATION


Customer Information: The information in this installation instruction is intended for use only by skilled technicians who have the proper tools, equipment, and training to correctly and safely add equipment to your vehicle. These procedures should not be attempted by “do-it-yourselfers.”

1. Make sure you have the anti-theft code for the radio, then write down the frequencies for the preset buttons.
2. Disconnect the negative cable from the battery.


3. Tilt the driver's side and passenger's side seatback forward.
4. Open the caps of the two hooks, undo the two bolts, and remove the two hooks. Release the five clips, and remove the left seatback cover.
5. Release the five clips, and remove the right seatback cover.




6. Remove the rear tray trim (three clips and two retaining tabs).




7. Remove the four clips from the rear tray.
8. Gently pry up on the rear tray to release the four clips, and remove the rear tray.




9. Open the soft top in the open position as shown.




10. Remove the rear console back board (two self-tapping screws, three clips, and four retaining tabs).
11. Remove the three self-tapping screws at the area shown.




12. Loosen the lock nut, and remove the shift knob by turning it counterclockwise. Then remove the lock nut.
13. Pull the center console panel out toward you to release the eight clips.
14. Unplug the two vehicle connectors, and remove the center console panel.




15. Open the rear console lid and glove box lid, then remove the five self-tapping screws and four flat head self-tapping screws to the rear console.
16. Pull the rear console to the front side to release the two clips.
17. Unplug the two vehicle connectors, and remove the rear console.




18. Open the trunk lid, and remove the tool tray. Remove the seven clips that secure the left trunk side trim panel, and remove the panel.



19. Route the 14-pin connector end of the bus cable into the trunk from the inside the cabin as shown.




20. Pull out the bus cable into the trunk room.
21. Using a cleaner, thoroughly clean the area where the cushion tape will be wrapped. In the left of the trunk, to prevent the bus cable from interfering with the bolt on the vehicle bracket, wrap the cushion tape around the vehicle bracket.




22. Connect the bus cable.

Standard Model


1. Pull out the vehicle sub harness from the fuel tank by cutting the vehicle clip with wire tie. Take care not to damage the vehicle sub harness when cutting the wire tie.
2. Remove the vehicle clip with wire tie from the fuel tank.
3. Remove the tape from the vehicle sub harness, and free the harness. Remove the connector cap from the vehicle sub harness connector.



4. Install the connector cap removed in step 3 to the bus cable 2 port 14-pin connector as shown.
5. Connect the bus cable 2 port 14-pin connectors to the bus cable 14-pin connector and the vehicle sub harness 14-pin connector.
6. Secure the bus cable 2 port 14-pin connector with one wire tie as shown.
7. Attach the two cushion tapes to the bus cable 2 port 14-pin connectors connected in step 5 as shown.




8. Secure the bus cable 2 port and the bus cable to the vehicle harness with four wire ties as shown.




With CD Changer


1. Cut the wire tie that fasten the CD changer bus cable 14-pin connector to the vehicle harness, and pull out the CD changer bus cable 14-pin connector. Remove the connector cap from the CD changer bus cable 14-pin connector.



2. Install the connector cap removed in step 1 to the bus cable 2 port 14-pin connector as shown.
3. Connect the bus cable 2 port 14-pin connectors to the bus cable 14-pin connector and the CD changer bus cable 14-pin connector.
4. Secure the bus cable 2 port 14-pin connector with one wire tie as shown.
5. Attach the two cushion tapes to the bus cable 2 port 14-pin connectors connected in step 5 as shown.




6. Secure the bus cable 2 port, the bus cable and CD changer bus cable to the vehicle harness with four wire ties as shown.




With XM Radio


1. Loosen the two bolts that fasten the XM radio unit.
2. Pull the XM radio unit out toward you, and unplug the vehicle sub harness 14-pin connector to the XM radio unit.



3. Connect the bus cable 2 port 14-pin connector to the vehicle sub harness 14-pin connector and the bus cable 14-pin connector.
4. Attach the two cushion tapes to the bus cable 2 port 14-pin connectors connected in step -3, and secure the bus cable 14-pin connectors with one wire tie as shown.
5. Plug the bus cable 2 port 14-pin connector to the XM radio unit, and reinstall the XM radio unit.




6. Secure the bus cable to the vehicle harness with four wire ties as shown.




With XM Radio and CD Changer


1. Loosen the two bolts that fasten the XM radio unit.
2. Pull the XM radio unit out toward you, and unplug the CD changer bus cable 14-pin connector to the XM radio unit.




3. Connect the bus cable 2 port 14-pin connector to the CD changer bus cable 14-pin connector and the bus cable 14-pin connector.
4. Attach the two cushion tapes to the bus cable 2 port 14-pin connectors connected in step 3, and secure the bus cable 14-pin connectors with one wire tie as shown.
5. Plug the bus cable 2 port 14-pin connector to the XM radio unit, and reinstall the XM radio unit.




6. Secure the bus cable to the vehicle harness with four wire ties as shown.




23. Using a felt-tip pen, mark the Music Link harness as shown.




24. Using a pushpin, mark the rear console as shown.




25. To prevent damage, wrap electrical tape around the drill bit at a point about 30 mm away from the tip. While wearing eye protection, drill a 20 mm hole through the marked location. Remove all burrs from the drilled hole.




26. Route the Music Link harness DIN connector into the 20 mm hole in the direction shown.




27. Cut the grommet as shown. Attach the grommet to the Music Link harness, and seat the grommet into the 20 mm hole.




28. Using a cleaner, thoroughly clean the area where the cushion tape will be wrapped. Attach the Music Link harness to the rear console with a cushion tape.




29. Insert the Music Link adapter unit into the unit cushion.




30. Route the Music Link harness and bus cable as shown, and connect the Music Link harness DIN connector (white) and bus cable DIN connector (black) to the Music Link adapter assembly. Note the location of the connectors and the terminals.




31. Secure the Music Link adapter assembly to the vehicle harness with two long wire ties.




32. Secure the Music Link harness to the vehicle harness with a wire tie. (Align the mark scribed in the step 23 with the wire tie as shown.)
33. Secure the bus cable to the vehicle harness with a wire tie.



34. Bundle up the excess Music Link harness and bus cable, and secure them to the vehicle harness with two wire ties.



35. Reinstall the rear console.



36. Check that all wire harnesses are routed properly, and all connectors are plugged in.

37. Reconnect the negative cable to the battery.

38. Enter the customer's radio anti-theft code, and reset the radio station preset and the clock.

39. Reinstall all removed parts.

40. Turn the power of the audio unit ON. Check that "No Disc" is shown on the display with the mode being at the CD changer mode (recognized as CD changer 4).

NOTE: Whenever the battery is disconnected, the driver's AUTO function is disable.

41. Start the engine. Push down on the driver's window switch until the window is fully open.

42. Pull up on the driver's window switch fully to close the window completely, then hold the switch for 2 seconds or more.

43. Test the window AUTO function.