| ┌ ( <b>) HONDA</b> –                                    | Accessory                  | Application  | Publications No.                |
|---|----------------------------|--|---------------------------------|
| INSTALLATION  | AUTOMATIC DAY/NIGHT        | 2012 CIVIC   | All 45605<br>Issue Date         |
| INSTRUCTIONS  | MIRROR                     | COR 2 AND 4-DOOR   | APR 2011                        |
| PARTS LIST<br>Attachment Kit                            | A<br>P/                    | utomatic Day/Night Mirror K<br>N 08V03-TR0-100A  | it                              |
| P/N 08V03-TR0-100                                       | A                          | utomatic day/night mirror  |                                 |
| Automatic day/night mirror harness                      |                            | perating Instructions  |                                 |
| Harness cover   | Pł<br>Fi<br>Ri             | Source of the second se | JIRED                           |
| 6 Wire ties   | Is<br>SI<br>Di<br>PI<br>T2 | opropyl alcohol<br>nop towel<br>agonal cutters<br>astic Trim Tool (T/N SILTRIMT<br>20 TORX wrench  | ΓL10)                           |
| Clip  | Та                         | ashlight<br>ipe  |                                 |
|   |                            | ustration of the Automatic L<br>stalled in the vehicle<br>AUTOMATIC<br>DAY/NIGHT<br>MIRROR   | Day/Night Mirror                |
| Jrethane tape   |                            | AUTOMATIC<br>DAY/NIGHT<br>MIRROR<br>HARNESS  | Co l                            |
| Fuse label  |                            |  | 2A FUSE                         |
| © 2011 American Honda Motor Co., Inc. – All Rights Rese | vrved. All 45605 (1104     | )  | 08V03-TR0-1000-90 <b>1 of *</b> |

#### INSTALLATION

**Customer Information:** The information in this installation instruction is intended for use only by skilled technicians who have the proper tools, equipment, and training to correctly and safely add equipment to your vehicle. These procedures should not be attempted by "do-it-yourselfers."


1. Disconnect the negative cable from the battery.

If the vehicle is equipped with map lights, go to step 2, otherwise go to step 3.

2. Remove the left and right lenses from the map light console (four retaining tabs for each lens). Remove the two bolts.


#### With Moonroof

• Remove the map light console. Then unplug three vehicle connectors, and remove the switch (four retaining tabs).




### Without Moonroof and With Hands Free Link

• Remove the map light console (unplug two vehicle connectors).




Without Moonroof and Hands Free Link


• Remove the map light console (unplug the vehicle connector).



3. Remove the driver's and passenger's sunvisor holders.




4. Remove the cover (two retaining tabs).



5. While holding down the hook as shown, remove the rearview mirror from the mirror mount.

6. Wrap the tip of a flat-tip screwdriver with tape. Locate the slot in the bracket cover, and insert the flat-tip screwdriver into the slot. Push the hook with the screwdriver.




While pushing in on the hook, rotate the sunvisor backward about 45°.


7. While pushing in on the hook, rotate the driver's sunvisor backward about 45°. Make sure the hook slides into the bracket cover.

NOTE: If the hook did not stay pushed in, return the driver's sunvisor to its original position and repeat steps 6 and 7.

8. Remove the driver's sunvisor.




9. Pull the driver's door opening seal away from the A-pillar.




10. Pull out the driver's A-pillar trim to release the clips.

11. Put a shop towel in the opening between the driver's A-pillar trim and the dashboard to catch any A-pillar clips that drop.




12. Remove the driver's A-pillar trim from the upper clip and unplug the vehicle connector, if equipped. Carefully remove the shop towel and any clips that fell from the driver's A-pillar trim.


NOTE: The upper clip will stay in the body.




13. Remove the remaining upper clip from the driver's A-pillar.




14. Install the new clip to the driver's A-pillar trim.



15. Pull away the door opening seal from around the dashboard.




- 16. Remove the driver's dashboard side cover (three clips, two retaining tabs, and two hooks).
- 17. Remove the driver's dashboard lower cover (nine clips and unplug the vehicle connector, if equipped).



## Installing the Automatic Day/Night Mirror


18. Install the automatic day/night mirror on the mirror mount as shown, and tighten the TORX screw.

T20 TORX WRENCH



# **Routing the Automatic Day/Night Mirror Harness**


19. Using isopropyl alcohol on a shop towel, thoroughly clean the fuse case where the fuse label will attach.



20. Attach the 2A fuse label to the fuse case on the automatic day/night mirror harness.


#### Without Another Accessory Harness

21. Plug the automatic day/night mirror harness 6-pin connector into the fuse box 6-pin connector.




# With Another Accessory Harness

22. Unplug the other accessory harness 6-pin connector from the fuse box 6-pin connector.



- 23. Plug the automatic day/night mirror harness 6-pin connector into the fuse box 6-pin connector.
- 24. Remove the dummy connector from the automatic day/night mirror harness 6-pin connector, and plug the other accessory harness 6-pin connector into the automatic day/night mirror harness 6-pin connector.
- 25. Route the automatic day/night mirror harness to the driver's dashboard lower cover opening as shown.




26. Secure the automatic day/night mirror harness to the vehicle harness with one wire tie.


# For Si models, go to step 28. For other models, continue to step 27.

 Plug the vehicle 5-pin connector (blue) or, if equipped, the ambient light harness 5-pin connector (green) to the automatic day/night mirror harness 5-pin connector. Go to step 30.


NOTE: If the vehicle is equipped with an ambient light switch, do not plug the 5-pin connector (blue) to the automatic day/night mirror harness 5-pin connector.




28. Unplug the vehicle 5-pin connector (blue) or, if equipped, the ambient light harness 5-pin connector (green) from the VSA switch, and plug it into the automatic day/night mirror harness 5-pin connector. NOTE: If the vehicle is equipped with an ambient light switch, do not plug the 5-pin connector (blue) to the automatic day/night mirror harness 5-pin connector.




29. Plug the automatic day/night mirror harness 5-pin connector (blue) to the VSA switch.




30. Using one wire tie, secure the automatic day/night mirror harness to the vehicle harness as shown.



31. Route the automatic day/night mirror harness toward the outside of the vehicle as shown.




AUTOMATIC DAY/NIGHT MIRROR HARNESS 32. Route the automatic day/night mirror harness between the dashboard and the driver's A-pillar.





33. Align the green tape on the automatic day/night mirror harness with the vehicle clip, and secure the automatic day/night mirror harness to the vehicle harness with one wire tie.

34. Route the automatic day/night mirror harness behind the headliner as shown. Be careful not to crease the headliner.




35. Plug the automatic day/night mirror harness 7-pin connector to the automatic day/night mirror.






36. Align the green tape on the automatic day/night mirror harness at the headliner as shown. Route the automatic day/night mirror harness through the groove in the harness cover. Secure the harness cover to the mirror stay, and put the top of the harness cover behind the headliner.


## 4-Door Models



2-Door Models




37. Using isopropyl alcohol on a shop towel, thoroughly clean the area where the urethane tape will attach.




38. Secure the automatic day/night mirror harness to the vehicle panel with one urethane tape as shown. Be careful not to crease the headliner.

39. Using three wire ties, secure the automatic day/night mirror harness to the vehicle harness as shown.



40. Non-Si models only: Plug the automatic day/night mirror harness 5-pin connector (blue) to the VSA switch.




41. Reinstall the driver's dashboard lower cover.

- 42. Check that all wire harnesses are routed properly and all connectors are plugged in.
- 43. Check the overlap between the headliner and the driver's A-pillar trim. Refer to the Service Manual. If necessary, adjust the overlap.
- 44. Reinstall all removed parts.
- 45. Reconnect the negative cable to the battery.
- 46. Press and hold the radio power button for two seconds to restore the radio and navi (if equipped) system functions.
- 47. Reset the clock.
- 48. If the IMA battery level gauge is at zero, start the engine and hold the rpm between 3,500 and 4,000 (no load) in P or N position until the Charge/Assist meter indicates the IMA system has stopped charging the battery.
- 49. Do the FUNCTION CHECK to verify the operation of the automatic day/night mirror.
- 50. Adjust the zone and calibrate as required.
- 51. Put the Operating Instructions in the glove box.


### **FUNCTION CHECK**

- 1. Turn the ignition switch to ON (II), but do not start the engine.
- 2. Turn on the switch. Check that the LED lights.

#### AUTOMATIC DAY/NIGHT MIRROR



3. Cover the front sensor in the automatic day/night mirror with your hand, and use a flashlight on the rear sensor in the automatic day/night mirror. Make sure the mirror surface becomes dim.



- 4. Make sure the parking brake is applied securely. Step on the brake pedal, and move the select lever to the "R" position. Repeat step 3, and make sure the mirror surface does not become dim.
- 5. If the automatic day/night mirror does not function properly, check the fuse and all connectors.