



INSTALLATION INSTRUCTIONS

Accessory

RUNNING BOARDS
P/N 08L33-S9A-100

Application

2004 CR-V

Publications No.


All 26138

Issue Date


SEP 2003

PARTS LIST


2 Running boards




6 Brackets A



6 Brackets B



6 Brackets C



72 Flange bolts




60 Flange nuts



Jack label



Owner's manual page



TOOLS REQUIRED

Ratchet

13 mm Combination wrench

13 mm Socket

Torque wrench


Isopropyl alcohol

Shop towel

INSTALLATION

Customer Information: The information in this Installation Instruction is intended for use only by skilled technicians who have the proper tools, equipment, and training to correctly and safely add equipment to your vehicle. These procedures should not be attempted by "do-it-yourselfers."


1. Position the three brackets B on the underside of the body, and install the two flange bolts for each bracket B. Torque all the flange bolts to 27 N·m (20 lb-ft).




FLANGE BOLT

BRACKET B


- Position the three brackets A in the brackets B you just installed, and install the six flange bolts and four flange nuts for each bracket A. Torque all the flange bolts to 27 N·m (20 lb-ft).




- Position the three brackets C in the brackets B, and install the two flange bolts and two flange nuts. Do not tighten them yet.




- Insert the six studs of the running board into the holes in the three brackets C, then install a flange nut on the end of each stud, but do not tighten the flange nuts yet.



5. Raise the running board to align the holes in the brackets B with the holes in the brackets C. Install and tighten the two flange bolts and the two flange nuts.




6. Adjust the front of the running board, so it's equal with the body line, then tighten the six flange nuts installed in step 4.



7. Tighten all the flange bolts installed in step 3.
8. Torque all the flange nuts and bolts to 27 N·m (20 lb-ft).
9. Repeat steps 1 through 8 to install the running board on the right side.

Installing the Jack Label

10. Remove the jack from the cargo area. Refer to the vehicle Owner's Manual in the glove box.



Using isopropyl alcohol, thoroughly clean the area where the caution label will attach.

11. Using isopropyl alcohol on a shop towel, clean the area where the caution label will attach.
12. Remove the adhesive backing from the jack label, and attach it to the jack in the area shown. Reinstall the jack in the cargo area.
13. Insert the owner's manual page from this kit into the vehicle Owner's Manual, and place the Owner's Manual in the glove box.