




INSTALLATION INSTRUCTIONS

Accessory	Application	Publications No.
HONDA MUSIC LINK	2006 PILOT	All 31182-31633
		Issue Date
		DEC 2005


PARTS LIST

Attachment Kit
P/N 08A28-1H1-800

4 Cushion tapes




Holder cushion




Grommet



8 Wire ties




2 Long wire ties




Music Link Adapter Kit

P/N 08A28-1H1-100A


Music Link adapter unit




Bus cable



Music Link harness



CD-ROM




Owner's Manual



BUS Cable 2 Port (sold separately)

P/N 08A31-0F1-000


BUS cable 2 port



TOOL AND SUPPLIES REQUIRED

#2 Phillips screwdriver
Flat-tip screwdriver
Diagonal cutters
Scissors
Ratchet
10 mm Socket
10 mm Combination wrenches
Felt-tip pen
Drill motor
Drill bit (3 mm)
Hole saw (20 mm)
Shop towel
Pushpin
Eye protection
Isopropyl alcohol
Electrical tape

Illustration of the Music Link System Installed on the vehicle




INSTALLATION


Customer Information: The information in this installation instruction is intended for use only by skilled technicians who have the proper tools, equipment, and training to correctly and safely add equipment to your vehicle. These procedures should not be attempted by "do-it-yourselfers."

1. Make sure you have the anti-theft code for the radio, then write down the frequencies for the preset buttons.
2. Disconnect the negative cable from the battery.


3. Remove the audio unit.
 - Remove the meter panel (two self-tapping screws and five clips).




- Remove the meter sub panel (three clips).




- Using a flat-tip screwdriver wrapped with a shop towel, gently pry out on the audio panel to remove the five clips. Unplug the connectors and remove the audio panel.




- Remove the four screws that fasten the audio brackets. Pull the audio unit out toward you, unplug the vehicle connectors and vehicle antenna connector from the rear of the audio unit.



- Lower the glove box by removing the right and left stops. Remove the two bolts under the glove box, then remove the glove box.




- Route the DIN connector end of the bus cable from the audio unit opening to the glove box opening.




- Secure the bus cable.

Without the 14-Pin Connector or Installed the Player in Audio Panel Opening

- Align the bus cable 14-pin connector with vehicle 20-pin connector and secure bus cable on the vehicle pipe with a wire tie.




- Bundle the bus cable 2 port and vehicle harness with two wire ties as illustrated.
- Align the bus cable 2 port 14-pin connector with the vehicle 20-pin connector, and secure the bus cable to the vehicle pipe with a wire tie.




With the Vehicle 14-Pin Connector

- Connect the bus cable 14-pin connector and vehicle 14-pin connector to the bus cable 2 port 14-pin connectors.
- Attach the two cushion tapes to the bus cable 2 port 14-pin connectors as shown.




With CD Changer or XM Radio


- Connect the bus cable 14-pin connector and CD changer bus cable 14-pin connector or XM radio harness 14-pin connector to the bus cable 2 port 14-pin connectors.
- Attach the two cushion tapes to the bus cable 2 port 14-pin connectors as shown.



3. Bundle bus cable 2 port and CD changer bus cable or XM radio harness with two wire ties as illustrated.
4. Align the bus cable 2 port 14-pin connector with the vehicle 20-pin connector, and secure the bus cable to the vehicle pipe with a wire tie.




3. Bundle bus cable 2 port and player bus cable with two wire ties as illustrated.
4. Align the bus cable 2 port 14-pin connector with the vehicle 20-pin connector, and secure the bus cable and player bus cable to the vehicle pipe with a wire tie.




Installed the Player in Audio Panel Opening and Underside Heater Control Unit


1. Connect the bus cable 14-pin connector and player bus cable 14-pin connector to the bus cable 2 port 14-pin connectors.
2. Attach the two cushion tapes to the bus cable 2 port 14-pin connectors connected in step 1 as illustrated.




8. Put a mark with a felt-tip pen on the illustrated location of the Music Link harness.
9. Cut one cushion tape in quarter, and wrap the three cut cushion tapes to the illustrated location of the Music Link harness.




10. To prevent damage, wrap electrical tape around the drill bit at a point about 30 mm away from the tip. While wearing eye protection, drill a 20 mm hole through the marked location. Remove all burrs from the drilled hole.




11. Route the Music Link harness DIN connector into the 20 mm hole in the direction shown.




12. Cut the grommet as shown. Attach the grommet to the Music Link harness, and seat the grommet into the 20 mm hole.




13. Clean the vehicle pipe with isopropyl alcohol where the cushion tape will attach. Attach a cushion tape to the vehicle pipe.




14. Insert the Music Link adapter unit into the holder cushion.




15. Route the Music Link harness through the glove box opening as shown, and connect the Music Link harness DIN connector (WHITE) to the Music Link adapter assembly. Note the location of the connector and the terminals.




16. Temporarily secure the Music Link adapter assembly and Music Link harness to the vehicle pipe with two long wire ties.




17. Secure the Music Link harness to the vehicle harness with a tire tie. (Align the mark scribed in the step 8 with the wire tie as shown.)
18. Bundle up the excess Music Link harness, and temporarily secure it to the vehicle pipe with the two long wire ties temporarily secured in step 16.




19. Route the bus cable through the two long wire ties temporarily secured in the step 16, and connect the bus cable DIN connector (BLACK) to the i-Pod adapter assembly. Note the location of the connector and the terminals.
20. Bundle up the excess bus cable, and secure it to the vehicle pipe with the two long wire ties temporarily secured in step 16.



21. Reinstall the glove box.



22. Connect the vehicle connectors and bus cable 14-pin connector (or bus cable 2 port 14-pin connector) to the audio unit, and reinstall the audio unit.



23. Check that all wire harnesses are routed properly and all connectors are plugged in.
24. Reconnect the negative cable to the battery.
25. Enter the customer's radio anti-theft code, and reset the radio station presets and the clock.
26. Reinstall all removed parts.
27. Turn the power of the audio unit ON. Check that "No Disc" is shown on the display with the mode being at the CD changer mode (recognized as CD changer 4).

NOTE: Whenever the battery is disconnected, the driver's AUTO function is disable.

28. Start the engine. Push down on the driver's window switch until the window is fully open.
29. Pull up on the driver's window switch fully to close the window completely, then hold the switch for 2 seconds or more.
30. Test the window AUTO function.